



How to Change the Staples on Your Canon Series Machine

1. Open the front door of the finisher



2. Remove the staples cartridge from the cartridge carrier (Green Tab)



3. Press on both sides to remove the cartridge from the casing



For More Information:

Contact an Advance Expert:

410.628.0490 or Dispatch@advancestuff.com



4. Insert new cartridge into the casing until it clicks into position



5. Insert the staple cartridge into the cartridge carrier



6. Close the finisher door

[Click here to view our how-to video!](#)

For More Information:

Contact an Advance Expert:

410.628.0490 or Dispatch@advancestuff.com