



How to Set Common Scan Defaults on Your Ricoh/Savin IM Series

1. From your 'Home' screen



2. Select 'Scanner'
3. Select 'Send Settings'




4. Select 'Auto Color Select'

For More Information:


Contact an Advance Expert:

410.628.0490 or Dispatch@advancestuff.com



5. Select 'Resolution'

6. Select '300 dpi'




7. Select 'Ok'

8. Select 'Recall/Program/Change Program'

For More Information:


Contact an Advance Expert:

410.628.0490 or Dispatch@advancestuff.com



9. Select 'Program as Defaults'

10. Select 'Program'



11. Select 'Yes' to confirm

[Click here view our how-to video!](#)

For More Information:

Contact an Advance Expert:

410.628.0490 or Dispatch@advancestuff.com

advancestuff.com

WE LIVE
AND
BREATHE
THIS STUFF.™